
LANCASTER & MORECAMBE
MORECAMBE BAY
BOLTON-LE-SANDS
To Carnforth
STATION
HEST BANK
NORTH JUNC.
HEST BANK SOUTH JUNC.
BARE LANE JUNC
BARE LANE STA.
MORECAMBE
GOODS
STA.
PASS.
JUNCTION
HEST BANK JUNC.
EAST JUNC.
WEST Jn
TORRISHOLME
To Leeds
GREEN AYRE STA.
JUNC.
QUAY
JUNCTION
CASTLE STA. PASS.
LANCASTER
GOODS
River Lune
HEYSHAM
HARBOUR
MIDDLETON ROAD
From Belfast
From Glasson Dock
From Preston
CARNFORTH
From Barrow
SILVERDALE
To Carlisle
BURTON & HOLME
To Wennington
BORWICK
JUNCTION
JOINT GOODS (FUR. L&N.W. & F.&N.W. JNT)
JUNCTION (MEAN POINT)
JOINT PASS. (FUR. & L.&N.W.)
JUNCTION
CARNFORTH
MORECAMBE BAY
BOLTON-LE-SANDS
From Lancaster
EXPLANATION
FURNESS
FUR. & L&N.W. JOINT
FUR. & MID. JOINT
LONDON & NORTH WESTERN
MIDLAND

1905